



Removing top cover Incanto & Italia




1) Remove screw as take bean hopper out




5) Remove the bean hopper gasket (lift)



2) Remove screws from under pre-ground cover and remove pre-ground shoot.




6) Remove two screws from rear wall.




3) Remove two screw as shown by arrows



7) Lift up & remove top cover



4) Remove steam knob by pulling it away



8) Disconnect cup warmer & ground wires